



** Note: arrow should point opposite the flow of air*

REPAIR PARTS KIT (part no. IV-125R)

Diaphragm & Seals
3, 5, 6, 8, 9, 12, 15, 16, 18

Internal Parts
4, 7, 10, 11(2), 19

